

Contactors

CT1115/04, CT1130/04 CT1115/08, CT1130/08 CT1115/11, CT1130/11

1 pole AC and bi-directional DC NO contactors for 400 A, 800 A and 1,100 A

Catalogue C20.en






CT1115/08, CT1130/08 CT1115/11, CT1130/11

CT1115/04, CT1130/04 Single pole power contactors for AC and DC, 400 A, 1,500 V or 3,000 V Single pole power contactors for AC and DC, 800 A, 1,500 V or 3,000 V Single pole power contactors for AC and DC, 1,100 A, 1,500 V or 3,000 V

CT series - revolutionary method of arc quenching for both DC and AC

With the CT contactor series Schaltbau is introducing an innovative contactor concept to the market. The outstanding technical feature is the innovative combination of electromagnetic and permanent-magnetic blowout technology for electric arc control. The successful combination of these two principles greatly improves both switching functionality, reliability and forms a practical and economically impressive device concept.

The CT contactor concept is flexible and can be adapted to suit the needs of the customer. Due to its technical characteristics, its economical advantages, its compactness and versatility, the CT power contactor series is simply predestined for use in industrial and railway applications alike. The product family, which is currently being expanded, comprises a number of various design versions catering to a wide range of uses.



Features

Innovative design:

- 1 pole NO contactors, DC bidirectional or AC •
- Contactors for 400 A, 800 A or 1,100 A current rating
- Nominal voltage 1,500 V or 3,000 V
- Double-break contacts
- Reliable shutdown of smaller currents at higher voltages no critical current range
- Compact, rugged design

Universal use:

- Drive system with coil tolerance according to railway standards
- CCC approval for CT11xx/04, CT11xx/08 and CT11xx/11 (
- UL approval available for selected versions c Sus, a list of all UL types can be found here: schaltbau.info/ct-group-en

Excellent insulation properties:

Reinforced insulation between main circuit and control circuit/auxiliary circuit

Easy maintenance:

- Easy inspection and replacement of main contact tips
- Easy to replace arc chute

Applications

Main contactor for:

- Traction converters
- Inverters for auxiliary equipment .

Contactor for:

- Field circuits of motors
- Conventional resistor based traction units (retrofit) •
- Starter and compressor motors
- Heating circuits

Contactor for a host of industrial and railway applications:

- Locomotives
- Cranes .
- Mining




Competence

The success of a product is owed to its quality

The Schaltbau product line is clearly defined and keeps up with the technological requirements of today's markets. Behind every individual contactor you will find decades of experience in engineering and manufacturing. Contactors are remote-controlled electrical switches with which high currents and voltages can be switched. A control current activates the magnetic drive that closes and reopens the contacts of the load current circuit. The moment of switching off represents a special challenge. The air between the opening contacts becomes ionised and an electric arc is created in which the current continues to flow. The air between the contacts offers a great deal of electrical resistance, which creates temperatures of up to 10,000 °C. To prevent the contacts or even the entire device from being thermal destroyed, the electric arc must be driven out of the contact area into arc chambers to be stretched and cooled until it loses energy and finally dies out. In order to extinguish the electric arc within a few milliseconds we have incorporated some sophisticated solutions in our contactors. This experience helps us to develop reliable contactors for power plants,

computer centres and electrically powered vehicles.

Ordering code



IEC 60077-2 Railway applications – Electric equipment for rolling stock – Part 2: Electrotechnical components; General rules IEC 62497-1 Railway applications – Insulation coordination – Part 1: Basic requirements – Clearances and creepage distances for all electrical and electronic equipment IEC 61373 Railway applications – Rolling stock equipment – Shock and vibration tests

- IEC 60947-4-1 Low-voltage switchgear and controlgear Part 4-1: Contactors and motor-starters – Electromechanical contactors and motor-starters
- IEC 62236-3-2 Railway applications Electromagnetic compatibility Part 3-2: Rolling stock – Apparatus



Specifications Single pole power contactors for AC and DC, Nominal voltage = 1,500 V

schaltbau.com | Page 4

CT series

Series		CT1115/04	I CT1115/08 I	CT1115/11
Type of voltage Number of poles, configuration			DC (bidirectional), AC (f ≤ 60 Hz) 1x SPST-NO	
Electrical ratings of main circuit to IEC 60077-2				
Nominal voltage	U _n	1,500 V	1,500 V	1,500 V
Rated operating voltage	U _r	1,800 V	1,800 V	1,800 V
Rated insulation voltage	U _{Nm}	3,000 V	3,000 V	3,000 V
Rated impulse withstand voltage	U _{Ni}	15 kV	15 kV	15 kV
Pollution degree / Overvoltage category		PD3 / OV2	PD3 / OV2	PD3 / OV2
Switching overvoltages	@ U _e = 1,800 V	<9 kV (<11 kV @ T2 = 40 ms)	<9 kV (<11 kV @ T2 = 40 ms)	<9 kV (<11 kV @ T2 = 40 ms)
Conventional thermal current	و وو .,۵۵۵۰ ا _{th}	400 A *1	800 A	1,100 A
Component category	۰tn	A2	A2	A2
Short-circuit making capacity, new/used contacts		3.5 kA / 5 kA	4 kA / 8 kA	4 kA / 8 kA
Rated operating current I_{e} (@ operational frequency	(2)	5.5 107 5 107	41077 0107	
$DC, U_e = 1$ $DC, U_e = 3$,800 V (T2 = 15 ms) ,600 V (T2 = 15 ms)	300 A 	450 A 	450 A
Rated operating current I _e (@ operational frequency AC, U _e = 1,800 V (f = 16.7 AC, U _e = 3,600 V (f = 16.7 AC, U _e = 3,600 V (f = 16.7 AC, U _e = 3,600 V (f = 16.7 AC, U _e = 3,600 V (f = 16.7 AC) (f = 16.	$/ 50 \text{ Hz}; \cos \varphi = 0.8)$	400 A / 300 A /	/ 550 A 	/ 550 A
Rated short-circuit breaking capacity (T2 = 15 ms)	DC, $U_e = 1,200 V$ DC, $U_e = 1,800 V$ DC, $U_e = 3,600 V$	700 A 400 A	1,200 A 800 A 	1,200 A 800 A
Rated short-circuit breaking capacity (T2 = 1 ms)	DC, $U_e = 3,000 V$ DC, $U_e = 1,200 V$	 1,300 A	2,500 A	2,500 A
	DC, $U_e = 1,200 V$	900 A	1,800 A	1,800 A
	DC, $U_{e} = 3,600 V$			
AC, $U_e = 1,800$ AC, $U_e = 3,600$	0 V (f = 16.7 / 50 Hz) 0 V (f = 16.7 / 50 Hz) 0 V (f = 16.7 / 50 Hz) 0 V (f = 16.7 / 50 Hz)	1,000 A / 700 A 800 A / 500 A /	1,900 A / 1,400 A 1,500 A / 1,000 A /	1,900 A / 1,400 A 1,500 A / 1,000 A /
AC, $U_{e} = 1,800$	0 V (f = 16.7 / 50 Hz) 0 V (f = 16.7 / 50 Hz) 0 V (f = 16.7 / 50 Hz)	1,300 A / 1,000 A 1,000 A / 700 A /	2,200 A / 1,600 A 1,900 A / 1,200 A /	2,200 A / 1,600 A 1,900 A / 1,200 A /
Rated short-time withstand current I _{cw}	T < 100 ms	6 kA	8 kA	8 kA
Critical current range		None	None	None
Design				
Contact material		AgSnO ₂	AgSnO ₂	AgSnO ₂
Terminals / Torque		M10 / 16 20 Nm	M12 / 24 30 Nm	M12 / 24 30 Nm
Auxiliary contacts				600 f
Number and type Contact material Switching capacity Terminals	S826, T = 5 ms		0 (a ₁)* ² , 1x S870 (b ₀)* ² , 2x S826 or 4 Silver 24 V DC; 13.5 A @ 80 V DC; 7 A @ 11 Screws M3 / Flat tabs 6.3 x 0.8 mm	
Magnetic drive (monostable)				
Coil voltage Pollution degree / overvoltage category Coil tolerance	Us	24 / 36 / 48 / 72 / 110 V DC PD3 / OV2 -30 % +25 % Us	24 / 36 / 48 / 72 / 110 V DC PD3 / OV2 -30 % +25 % Us	24 / 36 / 48 / 72 / 110 V DC PD3 / OV2 -30 % +25 % Us
Coil power dissipation	@ U _s and T _a = 20 °C	Cold coil 55 W Warm coil 40 W	Cold coil 72 W Warm coil 54 W	Pull-in (1 s max.) 330 W Hold 50 W
Pull-in voltage, typical Pull-in time, typical	@ T _a = 20 °C @ T _a = 20 °C	0.6 x U _s 120 ms	0.6 x U _s 250 ms	0.6 x U _s 250 ms
Drop-off voltage, typical	$@ T_a = 20 C$ $@ T_a = 20 °C$	$> 0.08 \times U_s$	> 0.08 x U _s	> 0.08 x U _s
Drop-off time, typical	$@T_a = 20 °C$	60 ms	60 ms	60 ms
Coil design / Coil suppression		Standard coil	Standard coil	Double winding coil
Suppressor diode Double coil controller with integreated suppresso	or diode	•	•	
Coil terminal	aloue aloue	Cage clamp	Cage clamp	• Cage clamp
Degree of protection		cage clamp	IP00	cage clamp
Mechanical endurance		> 2 million operating cycles	> 2 million operating cycles	> 300.000 operating cycles
Vibration / shock	IEC 61373		Category 1, class B	
Mounting position	1201575		horizontal / vertical	
Temperatures Operating temperature / Sto	orage temperature nidity (EN 62498-1)	< 2.00	-40 °C +70 °C / -40 °C +85 °C 0 m above sea level / <75 % yearly av	verage
Weight	, (1.1 02 190 1)	11 kg	18 kg	20 kg
- 				SCHALTBAU

*1 With frequent switching under load the conv. thermal current I_{th} must be limited to 350 A.

*2 a1 and b0 according to IEC60077-2 (Aux. contact b0 - "well open" or mirror contact for feedback circuits of safety-relevant controls according to DIN EN 13849-1)

Specifications Single pole power contactors for AC and DC, Nominal voltage = 3,000 V

CT series

Series	CT1130/04	CT1130/08	CT1130/11	
Type of voltage Number of poles, configuration		DC (bidirectional), AC (f \leq 60 Hz) 1x SPST-NO		
Electrical ratings of main circuit to IEC 60077-2				
Nominal voltage U _n	3,000 V	3,000 V	3,000 V	
Rated operating voltage U _r	3,600 V	3,600 V	3,600 V	
Rated insulation voltage U _{Nm}	4,800 V	4,800 V	4,800 V	
Rated impulse withstand voltage U _{Ni}	25 kV	25 kV	25 kV	
Pollution degree / Overvoltage category	PD3 / OV2	PD3 / OV2	PD3 / OV2	
Switching overvoltages $@ U_e = 1,800 V$	< 14.4 kV	< 15 kV	< 15 kV	
Conventional thermal current	400 A *1	800 A	1,100 A	
Component category	A2	A2	A2	
Short-circuit making capacity, new/used contacts	3.5 kA / 5 kA	4 kA / 8 kA	4 kA / 8 kA	
Rated operating current I _e (@ operational frequency C2)				
DC, $U_e = 1,800 V (T2 = 15 ms)$				
DC, U _e = 3,600 V (T2 = 15 ms)	200 A	320 A	320 A	
Rated operating current I_e (@ operational frequency C2)				
AC, U _e = 1,800 V (f = 16.7 / 50 Hz; cosφ = 0.8) AC, U _e = 3,600 V (f = 16.7 / 50 Hz; cosφ = 0.8)	350 A / 280 A	/ 650 A	/ 650 A	
Rated short-circuit breaking capacity (T2 = 15 ms) DC, $U_e = 1,200$ V	900 A			
DC, U _e = 1,800 V	700 A	1,300 A	1,300 A	
DC, $U_e = 3,600 V$	400 A	750 A	750 A	
Rated short-circuit breaking capacity (T2 = 1 ms) $DC, U_e = 1,200 V$	2,000 A 1.600 A			
DC, U _e = 1,800 V DC, U _e = 3,600 V	1,600 A 800 A	2,500 A 1,300 A	2,500 A 1,300 A	
Rated short-circuit breaking capacity ($\cos \varphi = 0.8$)		.,	1,00011	
$AC, U_e = 1,200 V (f = 16.7 / 50 Hz)$	2,000 A / 1,200 A	/	/	
AC, $U_e = 1,800 V (f = 16.7 / 50 Hz)$	1,600 A / 900 A	2,300 A / 1,500 A	2,300 A / 1,500 A	
AC, $U_e = 3,600 \text{ V} (\text{f} = 16.7 / 50 \text{ Hz})$	900 A / 500 A	1,300 A / 900 A	1,300 A / 900 A	
Rated short-circuit breaking capacity ($\cos \varphi = 1$) AC, U _e = 1,200 V (f = 16.7 / 50 Hz)	2,500 A / 1,500 A	/	/	
$AC, U_e = 1,200 \text{ V} (1 = 10.7 \text{ / } 50 \text{ Hz})$ AC, $U_e = 1,800 \text{ V} (f = 16.7 \text{ / } 50 \text{ Hz})$	2,100 A / 1,200 A	2,900 A / 1,700 A	2,900 A / 1,700 A	
AC, $U_e = 3,600 \text{ V} (\text{f} = 16.7 / 50 \text{ Hz})$	1,300 A / 800 A	1,600 A / 1,300 A	1,600 A / 1,300 A	
Rated short-time withstand current $\rm I_{cw}$ $T < 100 ms$	6 kA	8 kA	8 kA	
Critical current range	None	None	None	
Design				
Contact material	AgSnO ₂	AgSnO ₂	AgSnO ₂ M12 / 24 30 Nm	
Terminals / Torque	M10 / 16 20 Nm	M12 / 24 30 Nm	IVI12 / 24 50 IVI11	
Nuxiliary contacts Number and type	1, 0	70 (a₁)*², 1x S870 (b₀)*², 2x S826 or 4	v 6076	
Contact material	17.30	Silver	X 3020	
Switching capacity S826, T = 5 ms	16 A @	24 V DC; 13.5 A @ 80 V DC; 7 A @ 11	10 V DC	
Terminals		Screws M3 / Flat tabs 6.3 x 0.8 mm		
lagnetic drive (monostable)				
Coil voltage U _s	24/36/48/72/110VDC	24/36/48/72/110 V DC	24 / 36 / 48 / 72 / 110 V DC	
Pollution degree / overvoltage category Coil tolerance	PD3 / OV2 -30 % +25 % Us	PD3 / OV2 -30 % +25 % U _s	PD3 / OV2 -30 % +25 % Us	
Coil power dissipation $@U_s \text{ and } T_a = 20 ^{\circ}\text{C}$	Cold coil 55 W	Cold coil 72 W	Pull-in (1 s max.) 330 W	
	Warm coil 40 W	Warm coil 54 W	Hold 50 W	
Pull-in voltage, typical $@T_a = 20 \degree C$	0.6 x U _s	0.6 x U _s	0.6 x U _s	
Pull-in time, typical $@T_a = 20 \degree C$	120 ms	250 ms	250 ms	
Drop-off voltage, typical $@T_a = 20 \degree C$	> 0.08 x U _s	> 0.08 x U _s	> 0.08 x U _s	
Drop-off time, typical @ $T_a = 20 ^{\circ}C$	60 ms	60 ms	60 ms	
Coil design / Coil suppression Suppressor diode	Standard coil	Standard coil	Double winding coil	
Double coil controller with integreated suppressor diode			•	
Coil terminal	Cage clamp	Cage clamp	Cage clamp	
Degree of protection		IPOO		
Achanical endurance		> 2 million operating cycles		
/ibration / shock IEC 61373		Category 1, class B		
Aounting position		horizontal / vertical		
Temperatures Operating temperature / Storage temperature		-40 °C +70 °C / -40 °C +85 °C		
Altitude / Humidity (EN 50125-1)		00 m above sea level / < 75 % yearly av	-	
Weight	13 kg	21 kg	23 kg	


*1 With frequent switching under load the conv. thermal current I_{th} must be limited to 350 A.


*2 a1 and b0 according to IEC60077-2 (Aux. contact b0 - "well open" or mirror contact for feedback circuits of safety-relevant controls according to DIN EN 13849-1)






CT1115/04 Dimension diagram single pole NO contactor for 1,500 V / 400 A





CT1115/08 Dimension diagram single pole NO contactor for 1,500 V / 800 A



* Interrupting at maximum capacity could require larger clearance! Feel free to contact us, we will be happy to assist you with dimensioning.


CT series

CT1130/04 Dimension diagram single pole NO contactor for 3,000 V / 400 A

CT series


0 **SCHALTBAU**

Connect Contact Control



CT1130/08 Dimension diagram single pole NO contactor for 3,000 V / 800 A

422 392 369 218 6 Ó E open H op 1 347 ٩ 334 ¢ 2 1 t. ۲ 149 ⊕ 230 426




* Interrupting at maximum capacity could require larger clearance! Feel free to contact us, we will be happy to assist you with dimensioning. CT series



CT1115/11 Dimension diagram single pole NO contactor for 1,500 V / 1,100 A

CT series



* Interrupting at maximum capacity could require larger clearance! Feel free to contact us, we will be happy to assist you with dimensioning.


CT series

Circuit diagrams

• Versions according to railway standard for railway applications or with mirror contact for industrial applications

CT1115/04, CT1130/04, CT1115/08, CT1130/08

Main contacts	$1x \text{ NO, I}_{\text{th}} = 400 \text{ A} / 800 \text{ A}$					
Aux. contacts (EN 60077)	2 x S826, 1 x S870(b0), 1 x					
Magnetic drive	Coil suppression «T» Standard coil with suppre					
Circuit diagram	A1 1 13 11+					



S826

S826

S826

S870

S870

S870

S826

S870

CT1115/11, CT1130/11

Main contacts	1x NO, I _{th} = 1,100 A			
Aux. contacts (EN 60077)	2 x S826, 1 x S870(b0), 1 x S870(a1)			
Magnetic drive	Coil suppression «CM» Double coil controller (DCC) with integreated suppressor diode for magnetic drives with double winding coil			
Circuit diagram	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$			

• Versions for industrial applications without mirror contact

CT1115/04, CT1130/04, CT1115/08, CT1130/08

Main contacts Auxiliary contacts Magnetic drive


Circuit diagram

4 x S826

Coil suppression «T»

Standard coil with suppressor diode

 $1x \text{ NO}, I_{\text{th}} = 400 \text{ A} / 800 \text{ A}$



CT1115/11, CT1130/11

Main contacts

Magnetic drive

Circuit diagram

1x NO, I_{th} = 1,100 A Auxiliary contacts

4 x S826


A1

Coil suppression «CM» Double coil controller (DCC) with integreated suppressor diode for magnetic drives with double winding coil

DCC 12 24 3, S826 S826 S826

S826


CT1130/11 Dimension diagram single pole NO contactor for 3,000 V / 1,100 A




* Interrupting at maximum capacity could require larger clearance! Feel free to contact us, we will be happy to assist you with dimensioning.

Mounting holes

• Single pole NO contactor, CT1115/04, CT1130/04 series



• Single pole NO contactor, CT1115/08, CT1130/08 series



Mounting plate: bottom view

The thickness of the mounting plate is:


- CT1115/04, CT1130/04: 8 mm
- CT1115/08, CT1130/08: 10 mm
- CT1115/11, CT1130/11: 10 mm



Connect Contact Control

------ o SCHALTBAU


- CT series
- Single pole NO contactor, CT1115/08, CT1130/08 series





CT series

Mounting instructions



Dimensioning instructions

- Do you need some help? For selecting the contactor that suits your application best do not hesitate to ask our advice.
- For connection of the main contacts Schaltbau recommends the use of busbars with the following dimensioning:
 - Conv. thermal current $I_{th} = 400 \text{ A}$: 60 x 5 mm
 - Conv. thermal current I_{th} = 800 A: 80 x 8 mm
- Observe clearance of live parts to arc chute! Refer to dimension drawings on page 4 and 5 for data.
- For high switching loads at U_n ≥ 3,000 V DC a special design CT1130/08 ... 200 with adjusted blow-out coils is available.

Start up

Before initial start up make sure that:

- the arc chute is mounted properly and the lock bars are locked in position
- the protective covers are mounted properly
- the contactor is earthed (PE terminal on mounting plate)

Coil suppression

Coil suppression »T«, suppressor diode: Coil suppression for reducing surges when the coil is switched off is optimally attuned to the contactor's switching behaviour. Caution: Parallel connection with a simple diode will override the existing coil suppression.

Taking off the arc chute:

- 1. Push both release sliders in the direction indicated by the arrow and hold them in this position.
- 2. Move all four levers for unlocking the arc chute in the direction indicated by the arrow.
- 3. The arc chute incorporating the stationary main contacts can now be lifted from the contactor.

Mounting the arc chute:

- Mount the arc chute onto the magnetic drive. Note: The arc chute has keys on one side to fit into slots on the corresponding side of the contactor. So you cannot mount it the wrong way round.
- 2. Move all four levers for unlocking the arc chute into the original position.
- 3. Check: The arc chute is locked properly, if all four lock bars click into place and cannot be opened without pushing the release slider.

Disassembly of protective covers:

- Protective cover auxiliary switches: Dismount arc chute first, then loosen knurled head screws and remove protective cover.
- Protective cover coil terminals: Unscrew cover and take it off.

Assembly of protective covers:

- Protective cover auxiliary switches: Position protective cover and screw in both knurled head screws. Then mount arc chute.
- Protective cover coil terminals: Introduce protective cover into the groove of the coil drive and locate in position. Then tighten screws.

Spare parts


Item

	Spare part, description	Ordering code					
ns		CT1115/04	CT1130/04	CT1115/08	CT1130/08	CT1115/11	CT1130/11
	Stationary contact, complete – order 2 per pole	MC CT1015/04	MC CT1030/04	MC CT1015/08	MC CT1030/08	MC CT1015/11	MC CT1030/11
	Contact bridge with mounted contact holder, mounting position »H«	CBH CT1015/04	CBH CT1030/04	CBH CT1015/08	CBH CT1030/08	CBH CT1000/08	
	Contact bridge with mounted contact holder, mounting position »V«	CBV CT1015/04	CBV CT1030/04	CBV CT1015/08	CBV CT1030/08		
	Ceramic protection inserts – order 2 per pole	PI CT1030/04		PI CT1000/08			
	Protective cover coil terminals	CC CT1030/04		CC CT1030/08			
	Protective cover aux. switches	CA CT1030/04		CA CT1030/08			
	Snap-action switch (SPDT)	S826 a L					
	Contact block of 2x S870 (momentary switches a1, b0)	AS 5870					




CT series

Mounting positions




- H) Horizontal: Yellow lock bars ► Mounting position »H«
 - ✓ Vertical: Red lock bars ► Mounting position »V«
 -) Horizontal/vertical: Blue lock bars > Mounting position »H« or »V«

Horizontal mounting:



Vertical mounting:



Mounting position:

Please observe the mounting position as shown on the nameplate. The permissible installation position can be recognized by the color of the lock bar.

Maintenance instructions



For detailed maintenance, safety and mounting instructions please refer to our operating manual C20-C21-M.en!

- CT series contactors are maintenance free with normal use.
- Make regular inspections once or twice a year. So when installing the contactor, make sure that there is enough space to remove and replace the arc chute with ease and that the main contacts become accessible for inspection.
- Frequent switching or switchung under high load may lead to increased wear of the manin contacts. In this case replacement of the main contacts may become necessary. For detailed information please refer to our manual.

Safety instructions

•

The switching device meets the requirements of basic insulation. Make sure the plate onto which the drive of the contactor is mounted is

- earthed in a vibration resistant way.Do not use contactor without properly mounted arc chute.
- Do not use contactor without property mounted are chute.
 The contactor has unprotected live parts and carries a label that warns
- The contactor has unprotected live parts and carries a label that warns
 of the hazard. This caution must be observed and the label must not be
 removed in any way.
- The required clearance of live parts to ground and other parts of the contactor is to be observed as well as the safety regulations of the applicable standards.
- Switching at maximum breaking capacity might require larger clearance! Do not hesitate to ask our advice for dimensioning.
- Do not use contactor without protective covers (for coil terminals and auxiliary switches).
- Coil suppression for reducing surges when the coil is switched off is
 optimally attuned to the contactor's switching behaviour. The existing
 opening characteristic must not be negatively influenced by parallel
 connection with an external diode.
- Improper handling of the contactor, e.g. when hitting the floor with some impact, can result in breakage, visible cracks and deformation.

Ņ

Defective parts must be replaced immediately!

CT series

SCHALTBAU

Schaltbau GmbH

For detailed information on our products and services visit our website or give us a call!

Schaltbau GmbH Hollerithstrasse 5 81829 Munich Germany



Phone Fax

+49 89 9 30 05-0 +49 89 9 30 05-350 Internet www.schaltbau.com e-Mail contact@schaltbau.de

IRIS Certification

 $\left[\right]$

with compliments:

Np**ōkespogchuszt Sochfalttilätie@of**bH Свания со страниций страна и страниций страна и страниций страна и страна и страниций страна и стран качества IRIS.



Имебетсі і брана і мала і м с 2002 відде 2009 година і мала і м о сертивникатаж тіфедтеллівітена на нашиемерзитее.



Cel/tivifieeett toepottividea/klascoognoj01 DINSIENdeSiO9944.0001rthle9640soda. Актлуевонына алемліція о сертификатахилерезіцегавлена на нашем сайте.

Electrical Components and Systems for Railway Engineering and Industrial Applications

Connectors	 Connectors manufactured to industry standards
	 Connectors to suit the special requirements of communications engineering (MIL connectors)
	 Charging connectors for battery-powered machines and systems
	 Connectors for railway engineering, including UIC connectors
	 Special connectors to suit customer requirements
Snap-action switches	 Snap-action switches with positive opening operation
·	 Snap-action switches with self-cleaning contacts
	 Enabling switches
	 Special switches to suit customer requirements
Contactors	 Single and multi-pole DC contactors
contactors	 High-voltage AC/DC contactors
	 Contactors for battery powered vehicles and power supplies
	 Contactors for railway applications
	 Terminal bolts and fuse holders
	 DC emergency disconnect switches
	 Special contactors to suit customer requirements
	For view and for driver to ask
Electrics for rolling stock	Equipment for driver's cab
	Equipment for passenger use High-voltage switchgear
	 High-voltage switchgear High-voltage heaters
	 High-voltage roof equipment
	 Equipment for electric brakes
	 Design and engineering of train electrics to customer requirements